



Aufstellen von VZ 283-10 /  
VZ 283-20